IMAGING

Lambda Guidelines



With our advanced color management system, it's easy to get superior color from the Lambda.

Do's

- Use RGB images and colors in digital files
- Scans should be done at 100 dpi resolution, final size or higher
- Supply 1/2" bleed to ALL digital files
- Create soft drop shadows in Photoshop
- Provide the unflattened layered PSD file for correction purposes
- Create one single page for booth layouts
- Provide color samples of solid colors in digital file (if possible)

Don'ts

- DO NOT use CMYK images and colors
- DO NOT create soft drop shadows in Illustrator (causes outlines of boxes to appear where the shadows are placed)
- DO NOT save tiff files with LZW compression checked
- DO NOT create individual pages for each panel of a booth graphic
- DO NOT use Quark if final output exceeds 16 feet (no bleed available largest page size is 48 inches, thus at 400% max, equals 16 feet)
- DO NOT use stylized fonts in layout programs - ex) use the bold font, not a regular font bolded within the program

